



Daily Care
And
Cleaning Guide



Very Important

Rational Combi-Oven

Daily care

Exterior surface of unit

The exterior surface of the unit shall only be cleaned with a wet soft cloth. Aggressive or scouring cleaning agents are not allowed. Hosing down the unit with water jet or pressure cleaner is also not permitted.

Door glass

The inner door glass can be opened by releasing the 2 spring clips. Use only a wet soft cloth for cleaning of this surface. Aggressive or scouring cleaning agents are not allowed.

Door gasket



Temperatures of 220°C or higher together with continued use of grilling processes demand cleaning of the door gasket several times per day, ideally after every loading. Carefully wiping down the inner and outer side of the door gasket will extend the life time of the gasket considerably.

Please do NOT use any aggressive, scouring or vinegar-based cleaning agents for this purpose. Please do NOT run the unit idle at high temperatures for stand by purposes.

Drain of door drip pan



Please make sure the drain of the door drip pan is not blocked by fat or other foreign matter. Rinse daily with water from the hand shower and wipe with cloth.

CareControl



For hygiene reasons and to prevent malfunctions it is essential to clean the unit every day - risk of fire!

- Please note that your unit must be cleaned every day, even if only "steaming" operation is used.
- Use only the appliance manufacturer's cleaning agent and care tabs. The use of other chemical cleaners may damage the appliance. We will not be liable for the consequences!

CLEANING YOUR RATIONAL

1



- ✓ Ensure unit is cooled to below 40 degrees
- ✓ Remove all trays from within the unit.

2



- ✓ Remove all food debris from cabinet bottom.

3



- ✓ Clean door seal with soft cloth and warm soapy water

4



- ✓ Unclip the inner glass door and clean both sides with soft cloth and warm soapy water.



- ✓ Lock the inner glass door back into position.

5



- ✓ Clean the unit drip tray and the door channel tray.

6



- ✓ Select "Efficient CareControl" button

7



- ✓ Select required cleaning program
- ✓ Follow instructions as shown on-screen

8



- ✓ Lift the left side rack and swing open

9



- ✓ Place the indicated quantity of Cleaning tablets into the basket

10



- ✓ Remove care tablets from blue foil packet and place into the blue draw

11



- ✓ Close left side rack
- ✓ CLOSE door - wash program will start

12



On a weekly basis:

- ✓ Remove air filter and wash in hot soapy water or dishwasher
- ✓ Replace when completely dry

Equipment

- ✓ Soft non-abrasive cloth
- ✓ PPE
- ✓ Rational Cleaner Tabs and Care Tabs



NB. Please refer to operators manuals for further details